

Installation Instructions

Reservoir Cap RES-0004



Enclosed:

- 1 off Reservoir Cap
- 2 off M4 Fasteners



Image of finished installation.

Instructions:

- (1) Surround the reservoir cap with a clean cloth to stop any spillage.
- (2) Extract the two M4 countersink fasteners.
- (3) Remove the OEM cover from fluid pot.
- (4) **IMPORTANT** If your later style of reservoir has the plastic cover pictured below then this needs to be removed completely. This part is not needed as it is built into the replacement cap.
- (5) Place the new cap onto the unit.
- (6) Add the two M4 fasteners and tighten down to the manufactures torque settings.
- (7) Remove cloth and wipe away spilled fluid.

